

Installation Guide Guardrail



- 1** Mount **posts**:
Place height limiters on side panels.
Glue and screw posts in place.
- 2** Mount **triangular supports** on exit side:
Glue to the top edge of the casing and flush with the posts. Screw tight.
- 3** Screw tight **battens**:
Always start with one long side.
Reference:
2 post holes = outer grooves
1 post hole = middle groove
Pre-drill battens with \varnothing 3mm drill.
- 4** When all battens are screwed tight,
cut length if necessary.

